

Supporting Information

Electrochemical Lithiation of Covalently Bonded Sulfur in Vulcanized Polyisoprene

Chengyin Fu,¹ Guanghui Li,^{1,2} Jian Zhang,¹ Benjamin Cornejo,¹ Sophie S. Piao,³ Krassimir N. Bozhilov,⁴ Robert C. Haddon,^{1,2,5} Juchen Guo^{1*}


¹Department of Chemical and Environmental Engineering, University of California, Riverside, California 92521, United States

²Center for Nanoscale Science and Engineering, University of California, Riverside, California 92521, United States

³Division of Chemistry and Chemical Engineering, California Institute of Technology, Pasadena, California 91125, United States

⁴Central Facility for Advanced Microscopy and Microanalysis, University of California, Riverside, CA 92521, United States

⁵Department of Chemistry, University of California, Riverside, California 92521, United States



Scheme S1. Synthetic process of SPIP nanowires.




Figure S1. FTIR spectra of the pristine PIP, vulcanized SPIP-250, SPIP-300 and SPIP-350. The spectra of pristine PIP clearly show the C=C stretch at 1680 cm⁻¹, C-H and =C-H₂ stretches between 2850 cm⁻¹ to 3050 cm⁻¹. The magnitudes of all these peaks are reduced after vulcanization but remain detectable, indicating vulcanization reactions including free radical addition to the vinyl group and dehydrogenization of the allylic hydrogens.




Figure S2. Powder XRD pattern of SPIP-250, SPIP-300 and SPIP-350 compounds.

EAI ~ Elemental Analysis, Inc.

Thursday, April 14, 2016

Dr. Juchen Guo,
University of California, Riverside
900 University Ave Bourns Hall A220
Riverside CA 92521

Phone: (951) 827-6472
Email: jguo@cng.ucr.edu

EAI Project: 2749-16

Sulfur by Colorimetric Titration

<u>Sample ID</u>	<u>Sulfur (wt%)</u>
SSIP 250°C	49.13%
SSIP 300°C	48.25%
SSIP 350°C	25.45%

Respectfully Submitted,
Elemental Analysis Incorporated

Nick Tzouanakis,
Technical Sales Representative

2101 Capstone Drive, Suite 110, Lexington, KY 40511
Phone: 800-563-7493 / Fax: 859-254-5150 Email: Trace@ElementalAnalysis.com

Table S1. Sulfur content analysis of SSIP-250, SSIP-300 and SSIP-350 performed by Elemental Analysis Incorporated.




Figure S3. CV scans and cycle stability of SPIP compounds in electrolyte composed of 1 M LiPF₆ in ethylene carbonate/diethyl carbonate (50/50 volume ratio).




Figure S4. Complete three CV cycles of SPIP-250.




Figure S5. Complete three CV cycles of SPIP-300.




Figure S6. Complete three CV cycles of SPIP-350.




Figure S7. Parallel comparison of CV curves and charge-discharge potential profiles of each SPIP compound.