

Detailed Experimental

Apparatus. An apparatus for delivering known concentrations of organic vapors was constructed from solvent bubblers, solenoids, and mass flow controllers. Flow switching and data acquisition were computer controlled with LabVIEW software.

Fabrication of Substrates. Glass substrates for detector fabrication were prepared by evaporating 300 Å of chromium followed by 500 Å of gold onto microscope slides masked with a 3 mm strip of drafting tape down the center of the long axis. These slides were then cut down their short axis to give 15 smaller pieces from each slide.

Block Copolymer Synthesis. Polymers were prepared according to the procedure in reference 19. The mass ratio of monomer to catalyst was held constant (21:1) and the composition of the monomers was varied from 100% A to 100% B with five equally spaced compositions in between.

Fabrication of Sensors. Individual sensor elements for PMMA (poly (methyl methacrylate)) and PVC (poly (vinyl chloride)) detectors were prepared by spin coating films from tetrahydrofuran solutions onto the glass substrates. The electrodes and backs of the slides were cleaned with solvent prior to using the detectors. Five replicates of each detector were made for each experiment. Poly (styrene) (PS) detectors were prepared from benzene solutions on surface mount universal boards (surfboards, part 6012 from Capital Advanced Technologies) by dip coating. Poly (vinyl acetate) (PVA) sensors were prepared by spray coating (Iwata HP-BC airbrush) films from tetrahydrofuran onto glass substrates.

Experiments. Detectors were exposed to eight different solvents: methanol, ethanol, acetone, ethyl acetate, tetrahydrofuran, chloroform (methylene chloride in the case of the detectors formed from copolymers), toluene, and hexane. All exposures were adjusted to deliver the analyte at a concentration that was equal to 5% of the analyte's vapor pressure at room temperature. PVA- and PVC-based sensors were exposed 15 times to each solvent. Copolymers were exposed 20 times and the mean response over all exposures was reported.

Measurements. Detector resistance measurements as a function of time were recorded before, during, and after solvent exposure using a Keithley model 2002 multimeter attached to a Keithley model 7001 channel switcher. The average steady state dc resistance response of the composite was used to determine the differential resistance change of the detector in the presence of an analyte. Dividing this value by the baseline resistance yielded the relative differential resistance, $\Delta R/R$, which was the key quantity used to determine the response of a given composition of sensor to an analyte.

Data analysis. Detector responses to various solvents were analyzed through the use of the Fisher linear discriminant method. This method provides a measure of the resolving power of a given sensor array for the set of solvents. The result is a matrix of resolution factors describing the ability of the array to distinguish between pairs of solvents.

Detailed PVA resolution factors

Arrays of PVA with different numbers of sensors (5, 4, and 2) were examined for their ability to discriminate between various analytes. More detectors led to an increase in resolution factors. The magnitude of the effect depended, however, on the specific detector set and the analytes being resolved.

Resolution factors for a 5 sensor array with PVA and PVA with DGD, GTA, CP70, TCP

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	11.0	23.7	14.4	60.8	13.2	21.1	23.9
toluene		17.8	9.0	35.5	9.4	12.3	15.9
chloroform			9.0	8.6	7.7	9.4	10.8
THF				13.6	1.8	7.5	11.9
acetone					11.6	32.8	40.9
ethyl acetate						8.1	12.7
ethanol							6.4

Resolution factors for a 4 sensor array with PVA with DGD, GTA, CP70, TCP

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	10.6	20.6	14.3	60.8	13.0	19.6	23.0
toluene		14.2	8.9	34.3	9.0	9.2	11.3
chloroform			8.4	8.3	6.5	9.4	9.1
THF				12.9	1.7	5.0	7.1
acetone					9.5	32.7	36.7
ethyl acetate						7.0	8.9
ethanol							4.5

Resolution factors for a 4 sensor array with PVA and PVA with GTA, CP70, TCP

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	3.8	23.6	12.1	28.7	12.7	17.0	17.0
toluene		17.3	7.7	22.4	8.9	11.8	15.7
chloroform			8.6	4.9	7.3	7.9	8.8
THF				13.4	1.8	4.3	9.4
acetone					11.5	13.8	13.2
ethyl acetate						4.6	10.6
ethanol							6.4

Resolution factors for a 4 sensor array with PVA and PVA with DGD,
CP70, TCP

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	9.9	21.0	14.1	56.0	13.1	20.3	23.8
toluene		16.2	8.9	34.7	9.4	11.9	15.9
chloroform			8.7	8.6	7.6	8.9	10.2
THF				13.5	1.8	7.5	11.9
acetone					11.4	31.8	40.7
ethyl acetate						7.8	12.4
ethanol							6.4

Resolution factors for a 4 sensor array with PVA and PVA with DGD,
GTA, TCP

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	8.7	14.9	10.3	47.0	11.5	18.1	21.9
toluene		13.7	6.0	26.9	7.9	9.8	15.8
chloroform			8.0	6.5	7.5	8.6	10.8
THF				10.4	1.5	7.5	11.9
acetone					9.8	29.8	35.3
ethyl acetate						7.6	12.7
ethanol							6.3

Resolution factors for a 4 sensor array with PVA and PVA with DGD,
GTA, CP70

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	10.9	23.7	14.1	59.2	12.7	20.9	23.4
toluene		17.7	8.8	35.1	9.3	12.2	15.2
chloroform			9.0	7.8	7.7	9.3	10.8
THF				12.2	1.6	7.2	11.8
acetone					10.6	32.6	40.0
ethyl acetate						8.0	12.6
ethanol							6.4

Resolution factors for a 2 sensor array with PVA and PVA
with DGD

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	7.4	13.8	9.8	42.3	11.4	16.8	20.8
toluene		12.1	5.8	23.9	7.8	9.3	14.2
chloroform			7.8	5.7	7.3	8.3	10.1
THF				8.7	1.4	7.2	11.8
acetone					8.9	29.0	35.0
ethyl acetate						7.4	12.1
ethanol							6.2

Resolution factors for a 2 sensor array with PVA and PVA
with GTA

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	0.9	12.2	5.1	19.6	7.7	10.8	15.9
toluene		11.2	4.4	16.9	6.6	9.4	14.7
chloroform			5.5	1.4	5.4	1.7	4.9
THF				8.1	1.0	4.2	9.3
acetone					9.3	3.7	4.3
ethyl acetate						3.9	9.7
ethanol							6.2

Resolution factors for a 2 sensor array with PVA and PVA
with CP70

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	2.0	20.9	9.9	25.2	11.5	15.1	16.9
toluene		15.5	6.5	19.7	8.3	11.2	14.9
chloroform			7.6	3.6	6.5	5.9	4.7
THF				10.5	1.5	4.2	9.3
acetone					10.1	9.1	6.9
ethyl acetate						4.1	9.7
ethanol							6.4

Resolution factors for a 2 sensor array with PVA and PVA
with TCP

	Toluene	chloroform	THF	acetone	ethyl acetate	ethanol	methanol
hexane	2.3	12.3	7.2	18.6	7.9	10.9	16.1
toluene		10.5	4.3	15.0	5.7	9.3	15.3
chloroform			7.1	2.6	6.3	5.4	8.1
THF				10.2	1.4	4.2	9.4
acetone					9.3	6.9	9.5
ethyl acetate						4.2	10.3
ethanol							6.3

The pairwise odor discrimination performance of the electronic nose was evaluated using the Fisher linear discriminant algorithm. A resolution factor for any solvent pair can be obtained along any vector, \vec{w} , from the vector projection onto \vec{w} of the distance between the cluster centroids, $d_{\vec{w}}$, divided by the sum of the projected standard deviations, $\sigma_{a,\vec{w}}$ and $\sigma_{b,\vec{w}}$, for data arising from repeated exposures for two

different analytes, a and b . The resulting numerical resolution factor along \vec{w} is defined as:

$$rf = d_w / \sqrt{\sigma_{a,b}^2 + \sigma_{b,a}^2}$$

The Fisher linear discriminant operates by searching for the vector, \vec{w} , such that the rf value is maximized along this optimal discriminant vector.

Representative table of $\Delta R/R$ values for an array of PVA sensors

This table contains all the $\Delta R/R * 100$ response data used to determine the resolution factors presented above.

solvent	PVA	PVA+DGD	PVA+GTA	PVA+CP70	PVA+TCP
hexane	0.017	0.184	-0.170	0.003	0.122
hexane	0.018	0.195	0.039	0.021	0.153
hexane	0.017	0.189	0.150	0.023	0.107
hexane	0.010	0.116	0.153	-0.003	0.008
hexane	-0.019	0.120	0.144	0.026	-0.121
hexane	-0.025	0.112	-0.006	0.017	0.105
hexane	0.003	0.183	0.000	0.014	0.137
hexane	0.008	0.159	-0.164	0.027	-0.071
hexane	0.021	0.203	0.006	0.022	0.163
hexane	0.013	0.149	-0.148	0.033	0.182
hexane	0.020	0.312	-0.045	0.023	0.207
hexane	0.040	0.324	-0.012	0.012	0.729
hexane	-0.012	0.145	-0.056	0.026	-0.015
hexane	-0.008	0.293	0.073	-0.008	0.157
hexane	0.009	0.191	-0.009	0.022	0.104
toluene	-0.017	1.398	0.199	0.045	0.640
toluene	0.022	1.320	0.049	0.063	0.736
toluene	-0.009	1.296	0.389	0.064	0.587
toluene	0.020	1.267	0.199	0.049	0.959
toluene	0.029	1.241	0.018	0.057	0.702
toluene	0.023	1.276	0.042	0.053	0.662
toluene	0.052	1.623	0.098	0.018	1.402
toluene	0.043	1.169	-0.235	0.057	0.989
toluene	0.011	1.153	-0.117	0.058	0.695
toluene	0.038	1.202	-0.121	0.032	0.712
toluene	0.021	1.301	0.076	0.068	0.706
toluene	0.038	1.080	-0.086	0.090	0.599
toluene	0.037	1.386	-0.074	0.046	0.582
toluene	0.026	1.192	-0.023	0.084	0.636
toluene	0.066	1.438	0.124	0.079	1.150
chloroform	0.374	9.735	0.736	0.346	4.301
chloroform	0.355	7.966	0.618	0.328	3.606
chloroform	0.326	9.957	0.713	0.343	4.004
chloroform	0.347	7.841	0.827	0.319	3.188
chloroform	0.400	9.575	0.860	0.319	4.482
chloroform	0.370	9.510	0.760	0.346	4.199
chloroform	0.368	10.148	0.440	0.328	4.546
chloroform	0.323	10.556	0.607	0.353	5.219
chloroform	0.377	8.917	0.752	0.312	3.897

chloroform	0.371	9.978	0.360	0.359	4.038
chloroform	0.385	9.878	0.734	0.359	4.440
chloroform	0.347	9.921	0.792	0.334	4.427
chloroform	0.331	9.858	0.729	0.333	3.878
chloroform	0.364	10.109	0.754	0.322	4.533
chloroform	0.313	7.431	0.637	0.331	3.548
tetrahydrofuran	0.122	2.933	0.158	0.212	1.583
tetrahydrofuran	0.107	2.750	0.594	0.192	1.883
tetrahydrofuran	0.130	2.163	0.437	0.180	1.261
tetrahydrofuran	0.156	2.842	0.341	0.205	1.487
tetrahydrofuran	0.132	3.194	0.088	0.174	1.584
tetrahydrofuran	0.118	2.769	0.562	0.206	1.703
tetrahydrofuran	0.178	3.008	0.373	0.227	1.543
tetrahydrofuran	0.183	3.078	0.375	0.219	1.656
tetrahydrofuran	0.181	2.887	0.303	0.212	1.457
tetrahydrofuran	0.186	3.163	0.333	0.186	1.587
tetrahydrofuran	0.159	2.780	0.541	0.209	1.471
tetrahydrofuran	0.175	3.274	0.825	0.194	1.553
tetrahydrofuran	0.141	2.997	0.457	0.206	1.580
tetrahydrofuran	0.176	2.792	0.232	0.201	1.394
tetrahydrofuran	0.190	2.691	0.335	0.219	1.455
ethyl acetate	0.393	4.572	0.759	0.424	2.949
ethyl acetate	0.412	4.550	0.760	0.429	2.955
ethyl acetate	0.391	4.547	0.843	0.413	3.121
ethyl acetate	0.388	4.502	0.900	0.406	3.129
ethyl acetate	0.416	4.502	0.879	0.427	3.214
ethyl acetate	0.392	4.690	0.669	0.407	2.938
ethyl acetate	0.396	4.506	0.498	0.456	3.250
ethyl acetate	0.393	4.564	1.072	0.385	3.441
ethyl acetate	0.373	4.533	0.759	0.413	2.983
ethyl acetate	0.375	4.523	0.901	0.405	3.135
ethyl acetate	0.396	4.503	0.823	0.409	3.005
ethyl acetate	0.391	4.600	0.769	0.418	2.819
ethyl acetate	0.407	4.691	0.589	0.424	3.352
ethyl acetate	0.403	4.746	1.092	0.387	3.735
ethyl acetate	0.409	4.629	-0.025	0.403	3.102
acetone	0.139	3.621	0.510	0.227	1.873
acetone	0.186	3.497	0.280	0.250	1.587
acetone	0.210	3.212	0.407	0.246	1.617
acetone	0.220	3.677	0.067	0.246	1.690
acetone	0.194	3.309	0.457	0.251	1.697
acetone	0.200	3.294	0.495	0.221	1.574
acetone	0.189	3.293	0.560	0.221	1.819
acetone	0.213	3.506	0.399	0.247	1.804
acetone	0.165	2.730	0.325	0.216	1.449
acetone	0.181	3.384	0.430	0.237	1.679
acetone	0.193	3.272	0.323	0.228	1.545
acetone	0.192	3.216	0.356	0.234	1.570
acetone	0.211	3.834	0.411	0.242	2.036

acetone	0.194	2.811	-0.189	0.189	2.091
acetone	0.180	3.481	0.654	0.259	2.104
ethanol	0.303	1.473	0.434	0.224	1.146
ethanol	0.312	1.721	0.478	0.233	1.337
ethanol	0.312	1.510	1.091	0.188	1.279
ethanol	0.311	1.549	-0.141	0.234	0.823
ethanol	0.280	1.554	0.154	0.215	1.228
ethanol	0.294	1.601	0.369	0.220	1.112
ethanol	0.315	1.622	0.244	0.227	1.490
ethanol	0.307	1.546	0.331	0.208	1.602
ethanol	0.310	1.580	0.158	0.209	1.556
ethanol	0.279	1.687	0.884	0.214	1.432
ethanol	0.292	1.595	0.471	0.222	1.211
ethanol	0.280	1.589	0.215	0.234	1.216
ethanol	0.292	1.467	0.419	0.225	1.079
ethanol	0.351	1.537	0.358	0.223	1.140
ethanol	0.348	1.532	0.706	0.239	1.226
methanol	0.582	1.588	0.568	0.370	1.213
methanol	0.518	1.557	0.526	0.333	1.196
methanol	0.531	1.545	0.582	0.341	1.146
methanol	0.524	1.551	0.559	0.330	1.116
methanol	0.536	1.494	0.458	0.330	1.261
methanol	0.542	1.521	0.629	0.332	1.121
methanol	0.495	1.570	0.557	0.309	1.141
methanol	0.524	1.551	0.572	0.328	1.208
methanol	0.542	1.465	0.514	0.345	1.271
methanol	0.493	1.482	0.548	0.320	1.128
methanol	0.469	1.534	0.304	0.301	1.125
methanol	0.550	1.484	0.646	0.345	1.334
methanol	0.509	1.498	0.402	0.329	1.500
methanol	0.497	1.597	0.602	0.335	0.880
methanol	0.519	1.484	0.698	0.395	1.080