

# Structures and Spectroscopic Properties of Metalloporphyrin Nanoparticles

Julius Oppenheim<sup>†</sup>, Mike H. B. Gray<sup>†§</sup>, Angel J. Di Bilio<sup>†°</sup>, Bradley J. Brennan<sup>†</sup>, Lawrence M. Henling<sup>†</sup>, Punrajit Lim<sup>°</sup>, Matan Soll<sup>‡</sup>, John Termini<sup>°</sup>, Scott C. Virgil<sup>†</sup>, Zeev Gross<sup>‡</sup>, Harry B. Gray<sup>†\*</sup>

<sup>†</sup>Beckman Institute, California Institute of Technology, Pasadena, CA, 91125, USA

<sup>§</sup>Department of Chemistry, Occidental College, Los Angeles, CA, 90041, USA

<sup>°</sup>Department of Molecular Medicine, Beckman Research Institute of the City of Hope, Duarte, CA, 91010, USA

<sup>‡</sup>Schulich Faculty of Chemistry, Technion-Israel Institute of Technology, Haifa, 32000, Israel

## Supporting Information

Syntheses	2
XRD Refinement Details	3
Figure S1. Molecular structure of Au-tpfc	5
Figure S2. Photographs of M-tpfc samples	6
Figure S3. Luminescence behavior of Al-tpfc	7
Figure S4. Luminescence behavior of Al- Ga-tpfc	9
Figure S5. NTA results	10-13
Figure S6. TEM of Au-tpfc NPs	14
Figure S7. TEM of Ga-tpfc NPs	15
Figure S8. TEM of Al-tpfc NPs	16


Figure S9. UV-visible spectra of M-tpfc	17
Figure S10. Raman spectra of Au-tpfc	18
Figure S11. DFT Raman spectra of Au-tpfc	18
Figure S12. DFT Raman spectra of Al-tpfc	19
Figure S13. DFT Raman spectra of Ga-tpfc	20
Figure S14. DFT IR spectra of Ga-tpfc	20
Figure S15. IR and Raman spectra of free base tpfc	21
Figure S16. Crystal structure of Au-tpfc	22
ICP-MS	23
Figure S17. Calibration curves for Ga and Au standards	24
Table T1. Summary of NP characterization	25
Table T2. Calculations for NTA and ICP-MS analysis	26
Table T3. DFT Binding Energies on Ga-tpfc	27

**Syntheses.** Al-tpfc<sup>1</sup>, Ga-tpfc<sup>2</sup>, and tris-pentafluorophenyl corrole (H<sub>3</sub>-tpfc)<sup>3</sup> were prepared using literature procedures. Insertion of a gold atom into tpfc has been particularly challenging, with the highest-yielding route utilizing excess gold(III) acetate in pyridine solvent.<sup>4</sup> However, with a maximum Au-tpfc yield of ~12%, along with decomposition of non-metallated tpfc (plus the need for excessive gold precursor), this final step to product was inefficient. We improved the Au-tpfc synthesis, as follows: 393 mg H<sub>3</sub>-tpfc (0.49 mmol) were dissolved in 40 mL dichloromethane (in a dry flask). The flask was sealed with a septum and purged with inert gas. Separately, in a dry flask, 219 mg AuCl<sub>3</sub>•DMS (0.60 mmol) were dissolved in 20 mL


dichloromethane. To the vigorously stirring corrole solution we added (by syringe) 1.5 mL of 1.0 M potassium *tert*-butoxide in THF (1.5 mmol) followed immediately by the AuCl<sub>3</sub>•DMS solution. The solution turned green followed by red, and a precipitate formed. After 5 min, ~40 mL of silica gel were added to the reaction mixture, and the solvent was removed under reduced pressure. This was added on top of a silica filter column composed of 100 mL of silica gel, using 4:1 hexanes/dichloromethane as eluent. A red compound eluted first, and elution continued until the red faded and the eluent became green. The solvent was removed under reduced pressure to afford a brown solid. The product mixture was purified by silica gel column chromatography (1" x 12") using 4:1 hexanes/dichloromethane, and fractions were obtained. Those containing the pure product were combined and the solvent removed under reduced pressure to yield a purple/red solid that was subsequently washed with deoxygenated petroleum ether. Yield: 43%. <sup>1</sup>H NMR (300 MHz, CDCl<sub>3</sub>) δ 9.37 (d, *J* = 4.9, 2H), 9.00 (d, *J* = 4.9, 2H), 8.88 (d, *J* = 4.9, 2H), 8.83 (d, *J* = 4.9, 2H). <sup>19</sup>F NMR (300 MHz, CDCl<sub>3</sub>) δ -137.0 (m, 6F), -152.1 (m, 3F), -161.4 (m, 6F). Data collected in chloroform solutions using a 300 MHz Varian instrument was reported as ppm downfield of TMS (as internal standard). MALDI-TOF (*m/z*): M<sup>+</sup> calcd for C<sub>37</sub>H<sub>8</sub>AuF<sub>15</sub>N<sub>4</sub>, 990.02; found, 990.05. Mass spectrometry was performed using a Bruker Autoflex MALDI-TOF instrument using *trans*-2-[3-(4-*tert*-butylphenyl)-2-methyl-2-propenylidene]malononitrile as matrix. *Tert*-butoxide (1.0 M in THF) was obtained from Aldrich. Silica gel (F60) was obtained from Silicycle. HPLC-grade dichloromethane was stored over a drying agent.

**XRD Refinement Details.** A Au-tpfc crystal was mounted on a polyimide MiTeGen loop with STP Oil Treatment and placed under a nitrogen stream. Low temperature (100K) X-ray data were collected with a Bruker AXS D8 VENTURE KAPPA diffractometer running at 50 kV and


1 mA (Mo  $K_{\alpha}$  = 0.71073 Å; PHOTON 100 CMOS detector and Helios focusing multilayer mirror optics). All diffractometer manipulations, including data collection, integration, and scaling were carried out using the Bruker APEX3 software. An absorption correction was applied using SADABS. Au-tpfc crystallizes in the tetragonal space group  $I4_1/a$  with the asymmetric unit containing one and a half (on a two-fold axis) molecules along with solvent (chloroform and pentane) disordered over one site. The molecular structure is shown in Figure S1. The space group was determined and the structure solved by intrinsic phasing using XT. Refinement was full-matrix least squares on  $F^2$  using XL. All non-hydrogen atoms were refined using anisotropic displacement parameters. Hydrogen atoms were placed in idealized positions and refined using a riding model. The isotropic displacement parameters of all hydrogen atoms were fixed at 1.2 times (1.5 times for methyl groups) the  $U_{eq}$  value of the bonded atom.



**Figure S1.** Displacement ellipsoid view of the Au-tpfc molecular structure. Crystallographic data (CCDC 1914233) can be obtained free of charge from The Cambridge Crystallographic Centre via [www.ccdc.cam.ac.uk/structures](http://www.ccdc.cam.ac.uk/structures).




**Figure S2.** Freshly prepared Au-tpfc, Ga-tpfc-py, and Al-tpfc-(py)<sub>2</sub> NPs samples in 2% DMSO/water (left) and in 2% pyridine/water (right). The samples appeared stable over a 1-month.



**Figure S3.** Freshly prepared solution of Al-tpfc in pure DMSO (top, left) and colloidal Al-tpfc in 2% DMSO/water (top, right). Both samples contain the same amount of corrole monomers. No sign of precipitation was observed for the colloidal sample. The middle panel shows the samples

illuminated with UV light under fluorescent ambient lighting. The bottom panel shows the samples only illuminated with a UV lamp. Note the quenched emission of aggregated Al-tpfc.






**Figure S4.** Freshly prepared samples of colloidal Ga-tpfc (top, right) and colloidal Al-tpfc (bottom, right) in 2% DMSO/water under fluorescent ambient light. The Ga sample (top, left) and the Al sample (bottom, left) under illumination (from bottom) with a white light source.


Note the blue-purple scattered light attributed to enhanced resonance scattering in the Soret band region.

# NANOSIGHT

## Au




FTLA Concentration / Size graph for Experiment:  
Capture 2019-04-17 19-17-22



Averaged FTLA Concentration / Size for Experiment:  
Capture 2019-04-17 19-17-22  
Error bars indicate +/- 1 standard error of the mean

<p><b>Included Files</b></p> <p>Capture 2019-04-17 19-20-32 Capture 2019-04-17 19-23-37 Capture 2019-04-17 19-26-41</p> <p><b>Details</b></p> <p>NTA Version: NTA 3.2 Dev Build 3.2.16 Script Used: SOP Standard Measurement 07-17-22PM 17Apr2019.txt Time Captured: 19:17:22 17/04/2019 Operator: adb Pre-treatment: Sample Name: Au-tpfc 2 % DMSO 2nd run Diluent: Remarks: Au-tpfc 2% DMSO</p> <p><b>Capture Settings</b></p> <p>Camera Type: sCMOS Laser Type: Blue488 Camera Level: 8 Slider Shutter: 317 Slider Gain: 15 FPS: 25.0 Number of Frames: 4496 Temperature: 25.0 - 25.0 °C Viscosity: (Water) 0.9 cP Dilution factor: 1 x 10e2 Syringe Pump Speed: 15</p> <p><b>Analysis Settings</b></p> <p>Detect Threshold: 8 Blur Size: Auto Max Jump Distance: Auto: 17.0 - 17.1 pix</p>	<p><b>Results</b></p> <p>Stats: Merged Data</p> <p>Mean: 88.9 nm Mode: 75.7 nm SD: 22.8 nm D10: 66.7 nm D50: 83.2 nm D90: 111.9 nm</p> <p>Stats: Mean +/- Standard Error</p> <p>Mean: 88.9 +/- 0.7 nm Mode: 75.7 +/- 0.1 nm SD: 22.7 +/- 1.4 nm D10: 66.7 +/- 0.3 nm D50: 83.2 +/- 0.4 nm D90: 111.7 +/- 1.6 nm</p> <p>Concentration (Upgrade): 6.36e+010 +/- 1.70e+009 particles/ml 39.9 +/- 0.6 particles/frame 41.0 +/- 0.7 centres/frame</p>
--	--



Intensity / Size graph for Experiment:  
Capture 2019-04-17 19-17-22

**Figure S5.1** Complete list of experimental (left) and statistical (right) NTA parameters for Au-tpfc.






Figure S5.2 Complete list of experimental (left) and statistical (right) NTA parameters for Ga-tpfc.




FTLA Concentration / Size graph for Experiment:  
Capture 2019-04-18 16-29-19



Averaged FTLA Concentration / Size for Experiment:  
Capture 2019-04-18 16-29-19  
Error bars indicate +/- 1 standard error of the mean


Included Files		Results	
Capture 2019-04-18 16-32-46 Capture 2019-04-18 16-35-51 Capture 2019-04-18 16-38-56		Stats: Merged Data Mean: 100.5 nm Mode: 68.6 nm SD: 37.6 nm D10: 64.5 nm D50: 90.3 nm D90: 146.8 nm	
Details		Stats: Mean +/- Standard Error Mean: 100.6 +/- 0.9 nm Mode: 66.9 +/- 2.0 nm SD: 37.5 +/- 1.8 nm D10: 64.2 +/- 1.1 nm D50: 90.2 +/- 0.8 nm D90: 146.8 +/- 2.3 nm Concentration (Upgrade): 8.63e+010 +/- 1.58e+009 particles/ml 34.9 +/- 0.0 particles/frame 35.9 +/- 0.0 centres/frame	
NTA Version: NTA 3.2 Dev Build 3.2.16 Script Used: SOP Standard Measurement 04-29-19PM 18Apr2019.txt Time Captured: 16:29:19 18/04/2019 Operator: adb Pre-treatment: Sample Name: AI-tpfc 2 % DMSO DF = 50 Diluent: Remarks: AI-tpfc 2 % DMSO DF 50 +24 hrs after mixing.			
Capture Settings			
Camera Type: sCMOS Laser Type: Blue488 Camera Level: 8 Slider Shutter: 317 Slider Gain: 15 FPS: 25.0 Number of Frames: 4496 Temperature: 25.0 - 25.0 °C Viscosity: (Water) 0.9 cP Dilution factor: 2 x 10e2 Syringe Pump Speed: 15			
Analysis Settings			
Detect Threshold: 5 Blur Size: Auto Max Jump Distance: Auto: 16.4 - 17.5 pix			



Intensity / Size graph for Experiment:  
Capture 2019-04-18 16-29-19


**Figure S5.3** Complete list of experimental (left) and statistical (right) NTA parameters for AI-tpfc.






**Figure S6.** TEM images for Au-tpfc NPs prepared in 2% pyridine/water (room temperature). Panel A, 2.1 K magnification; panel B, 4.2 K magnification; panels C and D, 6.7 K magnification. Similar results were obtained for two different preparations. The images above were obtained from a sample, 24-hr-old. Images from a 3-week old sample were similar.






**Figure S7.** TEM images for Ga-tpfc NPs prepared in 2% pyridine/water (room temperature). Panel A, 1.1 K magnification; panel B, 2.1 K magnification; panels C and D, 4.2 K magnification. The images above were obtained from a sample, 24-hr-old. Images from a 3-week old sample were similar.






**Figure S8.** TEM images for Al-tpfc NPs prepared in 2% pyridine/water (room temperature). Panel A, 2.1 K magnification; panel B, 4.2 K magnification; panels C and D, 6.7 K magnification. The images were obtained from a 24-hr-old sample.






**Figure S9.** (Top and bottom) UV-visible absorption spectra in pure pyridine [ $\lambda_{\text{max}}$  (nm);  $\epsilon \text{ mol}^{-1} \text{cm}^{-1}$  for Au-tpfc [419.0;  $2.15 \times 10^5$ ]; Ga-tpfc-py [427.2;  $2.46 \times 10^5$ ]; and Al-tpfc-py<sub>2</sub> [432.2;  $2.41 \times 10^5$ ].


UV-visible absorption spectral data in pure DMSO [ $\lambda_{\text{max}}$  (nm);  $\epsilon \text{ mol}^{-1} \text{cm}^{-1}$  for Au-tpfc [416;  $2.18 \times 10^5$ ]; Ga-tpfc-py [420;  $2.63 \times 10^5$ ]; and Al-tpfc-(py)<sub>2</sub> [432;  $1.83 \times 10^5$ ].




**Figure S10.** Raman spectra (top to bottom): tpfc NPs in 2% DMSO; Au-tpfc NPs in 2% DMSO gel; Au-tpfc NPs in 5% DMSO; Au-tpfc crystal; 457.9 nm excitation.




**Figure S11.** (Top) Raman spectrum of Au-tpfc calculated using PBE0/LACV3P\*\* with a 0.96 vibrational shift and gaussian smoothing (standard deviation of 5  $\text{cm}^{-1}$ ). (Bottom) Experimental Raman spectrum of Au-tpfc in pyridine; 457.9 nm excitation.



**Figure S12.** (Top) Raman spectrum of Al-tpfc with 2 axial pyridines calculated using PBE0/6-31G with a 0.96 vibrational shift and gaussian smoothing (standard deviation of 5  $\text{cm}^{-1}$ ). (Bottom) Experimental Raman spectrum of Al-tpfc in pyridine; 457.9 nm excitation.




**Figure S13.** (Top) Raman spectrum of Ga-tpfc with 1 axial pyridine calculated using PBE0/6-31G with a 0.96 vibrational shift and gaussian smoothing (standard deviation of 5 cm<sup>-1</sup>). (Bottom) Experimental Raman spectrum of Ga-tpfc in pyridine; 457.9 nm excitation.




**Figure S14.** (Top) IR spectrum of Ga-tpfc with 1 axial pyridine calculated using PBE0/6-31G

with a 0.96 vibrational shift and gaussian smoothing (standard deviation of 5  $\text{cm}^{-1}$ ). (Bottom)  
Experimental IR spectrum of crystalline Ga-tpfc.





**Figure S15.** (Top) IR spectrum of free base tpfc; (Bottom) Raman spectrum of free base tpfc  
NPs in 2% DMSO; 457.9 nm excitation.



**Figure S16.** View of corrole packing in a Au-tpfc crystal. Crystallographic data (CCDC 1914233) can be obtained free of charge from The Cambridge Crystallographic Centre via [www.ccdc.cam.ac.uk/structures](http://www.ccdc.cam.ac.uk/structures).

**ICP-MS.** A stock solution of 2% HNO<sub>3</sub>, 1% HCl solution was made by adding 28 mL HNO<sub>3</sub> (70%) and 27 mL HCl (37%) to 945 mL mQ H<sub>2</sub>O and stored in a plastic bottle. A stock solution of concentrated acid (68% HNO<sub>3</sub>, 1% HCl) was made fresh by adding 0.27 mL HCl (37%) to every 10 mL HNO<sub>3</sub> (70%). 2.5, 5, or 15 µL of concentrated metallocorrole NPs in 2% DMSO/water or pyridine/water were added to a 15 mL metal free tube (SCP Science), representing three replicates for each metallocorrole NP. 500 µL concentrated acid (68% HNO<sub>3</sub>, 1% HCl) were added into each tube and allowed to digest at 80°C for a minimum of 15 min. 4.5 mL of the 2% HNO<sub>3</sub>, 1% HCl mQ solution were then added to each tube. A 1000 ppb (1 µg mL<sup>-1</sup>) standard containing gold was made by adding 150 µL of a 100 ppm (100 µg mL<sup>-1</sup>) gold standard (Spex CertiPrep) to 14.85 mL of 2% HNO<sub>3</sub>, 1% HCl mQ solution. A 1000 ppb gallium calibration standard solution was purchased from Spex CertiPrep. The 1000 ppb standard of gold or gallium was then serially diluted using the 2% HNO<sub>3</sub>, 1% HCl mQ solution to make a standard curve ranging from 1.95 to 1000 ppb. Samples were analyzed on an Agilent 8800 ISIS (discrete sampling) in no gas mode to determine gold or gallium concentrations. The 2% HNO<sub>3</sub>, 1% HCl solution in mQ water was used for both rinse and carrier solutions. Each sample was measured 5 times (technical replicates). A blank solution/calibration standard was measured after approximately every 10 samples as quality control to ensure that there was no carry-over between samples, and to check for instrument stability. The total amount of gold or gallium in 2.5, 5, or 15 µL of each concentrated metallocorrole NP sample was calculated by multiplying the measured concentration (ppb) with the 5 mL total volume of sample after dilution. Measurements below the lower limit of the standard curve were considered to be zero.



**Figure S17.** Calibration curves for gallium (a) and gold (b) standards over a concentration range of 1.95 to 1000 ppb.



**Table S1.** Hydrodynamic diameters measured by DLS and NTA and concentrations (measured by NTA) summary.

Metal-corrole NP		Hydrodynamic diameter (nm)		Concentration (particle mL <sup>-1</sup> )
Solv.	NP	DLS; Nanosight	PDI	
2% DMSO	Au-tpfc	89; 83	0.121	6.36 x 10 <sup>10</sup>
	Ga-tpfc	66; 57	0.097	15.4 x 10 <sup>10</sup>
	Al-tpfc	128; 90	0.319	8.63 x 10 <sup>10</sup>
2% pyridine	Au-tpfc	91; 71	0.065	4.84 x 10 <sup>10</sup>
	Ga-tpfc	78; 67	0.07	25.2 x 10 <sup>10</sup>

**Table S2.** Calculations and equations used to determine metal-corrole per particle for each metal-corrole NPs using paired NTA and ICP-MS analysis.

Samples	Nanoparticle Tracking Analysis (NTA)				ICP-MS					
	Median	SD	[Particle]	±Particle SE	Au	±Au SD	Au/mL	Au/mL	Au	Au
	(nm)	(nm)	(x10 <sup>8</sup> /mL)	(x10 <sup>8</sup> /mL)	(ppm)	(ppm)	(mol)	(molecules)	(particle <sup>-1</sup> )	(x10 <sup>5</sup> /particle)
<b>AuNP/2% DMSO</b>	83	23	636	17	8.975	1.214	4.56E-08	2.74E+16	431365.9	<b>4.3</b>
<b>AuNP/2% Pyridine</b>	72	15	484	103	10.836	0.581	5.50E-08	3.31E+16	684351.8	<b>6.8</b>

Samples	Nanoparticle Tracking Analysis (NTA)				ICP-MS					
	Median	SD	[Particle]	±Particle SE	Ga	±Ga SD	Ga/mL	Ga/mL	Ga	Ga
	(nm)	(nm)	(x10 <sup>8</sup> /mL)	(x10 <sup>8</sup> /mL)	(ppm)	(ppm)	(mol)	(molecules)	(particle <sup>-1</sup> )	(x10 <sup>5</sup> /particle)
<b>GaNP/2% DMSO</b>	57	16	1540	8	5.528	0.034	8.01E-08	4.82E+16	313303.4	<b>3.1</b>
<b>GaNP/2% Pyridine</b>	67	12	2520	25.1	6.107	0.197	8.85E-08	5.33E+16	211516.8	<b>2.1</b>

$$\text{mole of M / mL} = \frac{(\text{ppm of M})}{(\text{MW of M} \times 0.000001)}$$

M = gallium (Ga) or gold (Au)

MW of Ga = 69

MW of Au = 197

1 ppm = 1 µg / mL

$$\text{M / particle} = \frac{(\text{molecule of M / mL})}{(\text{particles / mL})}$$

$$\text{molecule of M / mL} = (\text{mole of M}) \times (6.022 \times 10^{23})$$

**Table S3:** Free energies (kcal/mol) associated with axial ligand binding to Ga-tpfc. All structures optimized with PBE-D3/LACV3P\*\*++.

	Free Energy (kcal/mol)	Ga-L Bond (Å)
DMSO (O-bound)	-41.4	1.99
DMSO (S-bound)	-8.7	2.82
H <sub>2</sub> O	-28.8	2.05
Pyridine	-35.9	2.10

## REFERENCES

- (1) Mahammed, A.; Gross, Z. Aluminum Corroline, a Novel Chlorophyll Analogue. *Journal of Inorganic Biochemistry* **2002**, 88 (3), 305–309. [https://doi.org/10.1016/S0162-0134\(01\)00373-7](https://doi.org/10.1016/S0162-0134(01)00373-7).
- (2) Bendix, J.; Dmochowski, I. J.; Gray, H. B.; Mahammed, A.; Simkhovich, L.; Gross, Z. Structural, Electrochemical, and Photophysical Properties of Gallium(III) 5,10,15-Tris(Pentafluorophenyl)Corrole. *Angewandte Chemie International Edition* **2000**, 39 (22), 4048–4051. [https://doi.org/10.1002/1521-3773\(20001117\)39:22<4048::AID-ANIE4048>3.0.CO;2-7](https://doi.org/10.1002/1521-3773(20001117)39:22<4048::AID-ANIE4048>3.0.CO;2-7).
- (3) Blumenfeld, C.; Fisher, K. J.; Henling, L. M.; Grubbs, R. H.; Gray, H. B.; Virgil, S. C. Control of Oligomerization and Oxidation Steps in the Synthesis of Tris(Pentafluorophenyl)Corrole. *European Journal of Organic Chemistry* **2015**, 2015 (14), 3022–3025. <https://doi.org/10.1002/ejoc.201500276>.
- (4) Soll, M.; Sudhakar, K.; Fridman, N.; Müller, A.; Röder, B.; Gross, Z. One-Pot Conversion of Fluorophores to Phosphorophores. *Org. Lett.* **2016**, 18 (22), 5840–5843. <https://doi.org/10.1021/acs.orglett.6b02877>.